



Arctic Fox LLC—570 South 7th Street—Delano, Minnesota 55328 USA  
 Phone: (800) 654-5382 or (763) 972-2758—Fax: (763) 972-2873—www.arctic-fox.com

Arctic Fox Europe—Strijmaden 5—4703 Roosendaal—The Netherlands  
 Phone: 31 (0) 165 55 9245—Fax: 31 (0) 165 54 9640—www.arctic-foxeurope.eu

## Thermostat—Coolant Shutoff

Used to regulate fuel temperature by controlling coolant flow through heat exchangers



S-400T / S-440T  
With A-289  
Steel Tee



S-400ST / S-440ST  
With A-284  
Steel Street Tee



S-400HT / S-440HT  
With A-289 Steel Tee  
(2) 1/4x20 Mounting Holes



S-400BT / S-440BT  
With A-289 Steel Tee  
Mounting Bracket, (2) Bolts & Washers

Used to control fuel temperature for any coolant type fuel warmer

- Model 400 stops coolant flow when fuel temperature through the Tee is approximately 78° to 95° F / 25° to 35° C
- Model 440 stops coolant flow when fuel temperature through the Tee is approximately 104° to 125° F / 40° to 52° C
- All fluid connections are 1/2" NPT

NOTE: Both models are coolant SHUT-OFF thermostats, any component or device connected in series with this product will NOT receive coolant once it is closed at the fuel temperatures shown.

### DIMENSIONS

